



## Triton II Phono Preamplifier Settings

### Capacitance S1, S4

Switch Position	Left Channel	Right Channel
No Switch On	0pF	0pF
Position 1	47pF	47pF
Position 2	150pF	150pF
Position 3	470pF	470pF
Position 4	1,000pF	1,000pF

### Resistance Loading S2, S5

	Left Channel	Right Channel
Position 1	20 Ohms	20 Ohms
Position 2	30 Ohms	30 Ohms
Position 3	100 Ohms	100 Ohms
Position 4	300 Ohms	300 Ohms

### Resistance Loading S3, S6

	Left Channel	Right Channel
Position 1	1 K Ohms	1 K Ohms
Position 2	47 K Ohms	47 K Ohms
Position 3	75 K Ohms	75 K Ohms
Position 4	100 K Ohms	100 K Ohms

### Gain in dB S7, S8

Switch Position	Left Channel	Right Channel
Position 1	43dB	43dB
Position 2	55dB	55dB
Position 3	60dB	60dB
Position 4	70dB	70dB